



C5 Corvette Supplement Install Guide

Use this guide in addition to the blip module install manual.

Prepare for installing the blip module in the glove box:

- ORG +12V: Thru a switch to any 12V ACC Ignition power source.
- BLK Ground: Connected to any chassis ground.
- YEL Clutch (Active LOW): Tap Grey wire on the 2 pin upper clutch switch connector
- BRN Brake: (Active HIGH): Tap the Blue wire on the 3 pin brake pedal switch connector.

C5 Corvette Throttle Pedal Harness

Keep the two 10 Pin connector "Y" in the drivers side foot well for throttle pedal connection and pass the single 6 pin connector to the passenger side foot well behind the center console.

- Remove the red locking clip from the throttle pedal female connector
- Unplug the female connector from the top of the throttle pedal.
- Plug that female connector into the Xineering Male 10 Pin connector.
- Connect the Xineering Female 10 Pin to the top of the throttle pedal

Make the +12V (thru a switch), Ground, Clutch AND Brake input connections.

Note: It is easier to tap the clutch wire by first disconnecting the 2 pin connector from the upper clutch switch for more clearance.

BRN = Brake ->

YEL = Clutch ->

