



2011-2014 Mustang Supplemental Install Guide


Use this guide in addition to the blip module install manual.

Prepare for installing the blip module in/near the glove box:

- **Ground:** BLK 22AWG (5ft)
Any solid vehicle ground will work.
- **+12V:** ORANGE 22AWG (5ft)
Locate a switched 12V source in the vehicle (12V key ON, 0V key OFF).
*An inline switch should be installed for disabling blips when unit is not needed (**switch not included**)*
- **Clutch:** YELLOW 22AWG (5ft)
Upper Clutch Position Switch:
- **Brake:** BROWN 22AWG (5ft)
Tap Pin 4 of connector C278 coming out of the brake light switch (blue housing).
See diagram below.

Pass the Clutch, Brake and throttle pedal harness behind the console from the passenger side footwell to the driver side footwell.



Make the Clutch and Brake connections at the appropriate switches.



Brake Light Switch Connector

Connector:	Description	Color	Harness	Base Part #	Service Pigtail
C278	BRAKE PEDAL POSITION (BPP) SWITCH	NA	14290	13480	See Below

Pin	Circuit	Gauge	Circuit Function	Qualifier
1	SBB24 (VT-RD)	20	FUSE - 24 OR CIRCUIT BREAKER	
2	GD119 (BK-BU)	20	GROUND - ENGINE COOLING FAN BRACKET	
3	CE509 (YE-GN)	20	SWITCH - BRAKE PEDAL # CRUISE CONTROL DEACTIVATION (BPS)	
4	CCB08 (VT-WH)	20	SWITCH - BRAKE ON/OFF (BPP) NORMAL OPEN	



Upper Clutch Switch Connector

Connector:	Description	Color	Harness	Base Part #	Service Pigtail
C277	CLUTCH PEDAL CRUISE CONTROL DEACTIVATOR SWITCH	BK	12638	7C534	See Below

Pin	Circuit	Gauge	Circuit Function	Qualifier
1	CE904 (GN-VT)	20	SWITCH - CLUTCH PEDAL POSITION # TOP OF TRAVEL (CPP-TT)	
2	*	*	Not Used	
3	GD129 (BK-YE)	20	GROUND - HEADLAMP PANEL LEFT	
4	*	*	Not Used	
5	*	*	Not Used	

